

REPAIR SHEET - Windshield wiper replacement.

REASON:

OPERATOR	WORKSHOP	DATE
REGISTRATION	TIME 0h 8min	COST

REQUIRED TOOLS				SAFETY	
☐	Flat screwdriver	☐		☐	Steel toe cap shoes
☐	13mm hexagonal wrench	☐		☐	
☐		☐		☐	
☐		☐		☐	
☐		☐		☐	

	TOOLS	PROCESS	ASSEMBLY DRAWING	ESTIMATED TIME
1		Removing the nut covers. To remove the nut covers, lift the covers up and pull them toward you.		1
		REMARKS		REAL TIME
2	Flat screwdriver, 13mm hexagonal wrench	Windshield wiper disassembly. 1- Using a 13mm wrench, loosen the nut on the right wiper shaft and remove it. 2- Using a flathead screwdriver, remove the circlip from the left shaft by prying it out. 3- To remove the wiper assembly, pull the tabs outward.		3
		REMARKS		REAL TIME
3	Flat screwdriver, 13mm hexagonal wrench	Windshield wiper assembly. 1- Fold and place the new wiper assembly so that the two shafts coming from the front fit into the two holes and so that the wiper blades are all the way to the left of the windshield (from the operator's point of view). 2- Using a 13mm wrench, screw in and tighten the nut on the right shaft. 3- Using a flat screwdriver, push the circlip until it clicks into place and then put the nut covers back on.		4
		REMARKS		REAL TIME