

Scoobic BioCargo Preventive Maintenance Guidelines 4Y



Mounth	4	8	12	16	20	24	28	32	36	40	44	48
Year	1			2			3			4		
Km	2000	4000	6000	8000	10000	12000	14000	16000	18000	20000	22000	24000
Miles	1242,742	2485,484	3728,226	4970,968	6213,71	7456,452	8699,194	9941,936	11184,678	12427,42	13670,162	14912,904

Items of Maintenance	Specs											
Batteries and charging system		●	●	●	●	●	●	●	●	●	●	●
Fault codes on screen		●	●	●	●	●	●	●	●	●	●	●
Brake pads (x4)		▲	▲	▲	▲	▲	▲	▲	▲	▲	▲	▲
Brake fluid bleed/Refill		●	●	●	●	●	●	●	●	●	●	●
Parking brake system, drawbar adjustment		●	●	▲	●	●	▲	●	●	▲	●	▲
Brake discs (x4)		●	●	●	●	▲	●	●	●	▲	●	●
Front tires	2,5 Bar Size 4.00 R12 C					▲						▲
Rear tires	3,0 Bar Size 4.80/4.00 R8			▲					▲			▲
Differential oil	SAE 85W90				▲		▲			▲		
Body and accessories, misalignment, deformation, rust		●	●	●	●	●	●	●	●	●	●	●
Chain steering system (grease the rear of the cassette)		●	●	●	●	●	▲	●	●	●	●	●
Steering system, steering wheel alignment		●	●	●	●	●	●	●	●	●	●	●
Lights, audible, and wiper blade (Wiper blade replacement)		●	●	●	●	●	▲	●	●	●	●	●

Rev. 28/04/2026

● Check

▲ Change

PM each 2.000km/4 mounths